

Owner's Manual

DVI Splitter with Audio and Signal Booster, 1080p 60 Hz

Models: B116-002A, B116-002A-INT
and B116-004A

Este manual está disponible en español en la página de Tripp Lite:
tripplite.com

Ce manuel est disponible en français sur le site Web de Tripp Lite :
tripplite.com

Dieses Handbuch ist in deutscher Sprache auf der Tripp Lite-Website
verfügbar: tripplite.com

WARRANTY REGISTRATION

Register your product today and be automatically entered to win an ISOBAR®
surge protector in our monthly drawing!

tripplite.com/warranty



1111 W. 35th Street, Chicago, IL 60609 USA • tripplite.com/support
Copyright © 2021 Tripp Lite. All rights reserved.

Package Contents

- B116-002A, B116-002A-INT or B116-004A Splitter
- External Power Supply with 4.5 ft. Cord
(Input: 100-240V, 50/60 Hz, 0.35A; Output: 5V 2A)
- (4x) International Plug Adapters (B116-002A-INT only)
- Mounting Hardware
- Owner's Manual

Product Features

- Delivers a single-link DVI-D video + audio signal to 2 (B116-002A and B116-002A-INT) or 4 (B116-004A) sets of DVI monitors and speakers
- Cascade up to 3 levels of splitters to expand the number of connected displays and speakers to 64
- Built-in signal booster increases the distance between the splitter and connected displays past the standard 16 ft. limitation
- Supports computer video resolutions up to 1920 x 1200 and HD resolutions up to 1080p
- International plug adapters allow connection to outlets in North America, U.K., Europe and Australia
- Compatible with HDCP, EDID and DDC standards
- Plug-and-play operation with no software required for easy, immediate installation
- Compliant with the Federal Trade Agreements Act (TAA) for GSA Schedule purchases

Optional Accessories

- B120-000* Dual-Link** DVI Extender
- P312-Series 3.5 mm Stereo Audio Cables
- P560-Series Dual-Link** DVI-D with 3.5 mm Audio Cable
- P561-Series Single-Link DVI-D Cables

*A B120-000 extender will only extend the DVI video signal, not the 3.5 mm audio.

** The B116-002A, B116-002A-INT and B116-004A splitters only support single-link DVI-D signals. Dual-link DVI cables and extenders can be used, but they will only transmit a single-link DVI-D signal.

Mounting Instructions

The B116-002A, B116-002A-INT and B116-004A include mounting hardware that allows them to be mounted in a variety of ways. The following images show the different ways the included mounting brackets can be attached for different mounting methods.


Wall Mount



19" Rack Mount




Pole Mount



Standard Installation

In a standard installation, there is only one splitter being used to connect two (B116-002A and B116-002A-INT) or up to four (B116-004A) sets of monitors and speakers. The following rules apply to a standard installation:

- The distance between the source and the splitter must not exceed 16 ft. (5 m).
- **For source video resolutions anywhere from 1600 x 1200 @ 60 Hz to 1920 x 1200 @ 60 Hz.** The distance between the splitter and the connected monitor and speakers must not exceed 49 ft. (15 m). The video distance can be extended by using a B120-000 DVI extender. The B120-000 can be located up to 65 ft. (20 m) from the splitter and 16 ft. (5 m) from the connected monitor.
- **For source video resolutions lower than 1600 x 1200 @ 60 Hz.** The distance between the splitter and the connected monitor and speakers must not exceed 65 ft. (20 m). The video distance can be extended by using a B120-000 DVI extender. The B120-000 can be located up to 114 ft. (35 m) from the splitter and 16 ft. (5 m) from the connected monitor.
- The B116-002A, B116-002A-INT and B116-004A are designed for monitor refresh rates of 60 Hz.



1. Make sure the DVI and Audio source is powered OFF.
2. Connect the DVI and Audio source to the input ports on the splitter using a Tripp Lite DVI with 3.5 mm Audio Cable (P560-XXX-A Series), or a Tripp Lite Single-Link DVI Cable (P561-Series) and 3.5 mm Audio cable (P312-Series).

Standard Installation


3. Connect a monitor and speakers to a set of available output ports on the splitter using a Tripp Lite DVI with 3.5 mm Audio Cable (P560-XXX-A Series) or a Tripp Lite Single-Link DVI Cable (P561-Series) and 3.5 mm Audio cable (P312-Series).
4. Repeat step 3 for each additional set of monitor and speakers you are connecting to the splitter.
5. Connect the included external power supply to the splitter and plug it into a Tripp Lite Surge Protector, Power Distribution Unit (PDU) or Uninterruptible Power Supply (UPS). The Power LED will illuminate to indicate the unit is receiving power.
6. Turn on the power to all connected monitors and speakers, then turn on the power to the DVI and Audio source. The Input Port LED will illuminate to indicate it is connected to a powered-on source. The Port LEDs will illuminate to indicate the corresponding port is connected to a monitor and speakers and is receiving a signal from the source.

Cascade Installation

The number of connected monitors and speakers can be expanded by cascading up to three levels of splitters together. By cascading a B116-004A from each port in a three-level installation, you can connect up to 64 sets of monitors and speakers. The following rules apply to a cascade installation:

- The distance between the source and the splitter must not exceed 16 ft. (5 m).
- **For source video resolutions anywhere from 1600 x 1200 @ 60 Hz to 1920 x 1200 @ 60 Hz.** The distance between the first-level splitter and any last-level splitter must not exceed 65 ft. (20 m). The video distance can be extended by using a B120-000 DVI Extender in between each level of splitters. Each B120-000 Extender can be located up to 32 ft. (10 m) from a splitter and 16 ft. (5 m) from the next level splitter or connected monitor.
- **For source video resolutions lower than 1600 x 1200 @ 60 Hz.** The distance between the first-level splitter and any last-level splitter must not exceed 98 ft. (30 m). The video distance can be extended by using a B120-000 DVI Extender in between each level of splitters. Each B120-000 Extender can be located up to 98 ft. (30 m) from a splitter and 16 ft. (5 m) from the next-level splitter or connected monitor.
- The B116-002A, B116-002A-INT and B116-004A are designed for monitor refresh rates of 60 Hz.

Cascade Installation



1. Make sure the DVI and Audio source are powered OFF.
2. Connect the DVI and Audio source to the input ports on the first-level splitter using a Tripp Lite DVI with 3.5 mm Audio Cable (P560-XXX-A Series) or a Tripp Lite Single-Link DVI Cable (P561-Series) and 3.5 mm Audio cable (P312-Series).
3. Connect a set of available output ports on the first-level splitter to the input ports on a second-level splitter using a Tripp Lite DVI with 3.5 mm Audio Cable (P560-xxx-A Series) or a Tripp Lite Single-Link DVI Cable (P561-Series) and 3.5 mm Audio cable (P312-Series).
4. Repeat step 3 for any additional splitters you wish to connect. Once you have connected a splitter to each set of ports on the first-level splitter, you can connect a third level of splitters to each set of ports on the second level. No more than three levels of splitters can be connected in a cascade installation.
5. Connect a monitor and speakers to a set of available output ports using a Tripp Lite DVI with 3.5 mm Audio Cable (P560-XXX-A Series) or a Tripp Lite Single-Link DVI Cable (P561-Series) and 3.5 mm Audio cable (P312-Series).
6. Repeat step 5 for each additional set of monitor and speakers you are connecting.
7. Connect the included external power supply to the first-level splitter and plug it into a Tripp Lite Surge Protector, Power Distribution Unit (PDU) or Uninterruptible Power Supply (UPS). The Power LED will illuminate to indicate the unit is receiving power.

Cascade Installation

- Repeat step 7 for each second-level splitter, then for each third-level splitter.
- Turn on the power to all connected monitors and speakers, then turn on the power to the DVI and Audio source. The Input Port LED will illuminate to indicate it is connected to a powered-on source. The Port LEDs will illuminate to indicate the corresponding port is connected to a monitor and speakers and is receiving a signal from the source.

Troubleshooting

If you are experiencing an issue with your splitter, trying the troubleshooting tips below may help to resolve the problem:

- Confirm that the Power LED is illuminated. If not, check if the external power supply is receiving power by plugging something else into the same power source. If it is receiving power, make sure the power supply is securely connected to the splitter. If the LED is still not illuminated, use a voltmeter to ensure the power source is providing enough power for the external power supply.
- Make sure that the cables you are using are functioning properly by connecting them directly between the source and display/speakers. Test all cables in the installation to make sure they are functioning properly.
- If the cables you are using are functioning properly, test each port on the splitter to make sure it is working. Using the cables you just tested, connect the source to the splitter, and then a set of output ports to a monitor and speakers. Test each port to make sure it is functioning properly.

Warranty & Product Registration

1-Year Limited Warranty

TRIPP LITE warrants its products to be free from defects in materials and workmanship for a period of one (1) year from the date of initial purchase. TRIPP LITE's obligation under this warranty is limited to repairing or replacing (at its sole option) any such defective products. To obtain service under this warranty, you must obtain a Returned Material Authorization (RMA) number from TRIPP LITE or an authorized TRIPP LITE service center. Products must be returned to TRIPP LITE or an authorized TRIPP LITE service center with transportation charges prepaid and must be accompanied by a brief description of the problem encountered and proof of date and place of purchase. This warranty does not apply to equipment which has been damaged by accident, negligence or misapplication or has been altered or modified in any way.

EXCEPT AS PROVIDED HEREIN, TRIPP LITE MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

Warranty & Product Registration

EXCEPT AS PROVIDED ABOVE, IN NO EVENT WILL TRIPP LITE BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. Specifically, TRIPP LITE is not liable for any costs, such as lost profits or revenue, loss of equipment, loss of use of equipment, loss of software, loss of data, costs of substitutes, claims by third parties, or otherwise.

PRODUCT REGISTRATION

Visit triplite.com/warranty today to register your new Tripp Lite product. You'll be automatically entered into a drawing for a chance to win a FREE Tripp Lite product!*

* No purchase necessary. Void where prohibited. Some restrictions apply. See website for details.

WARNING!

Use of this equipment in life support applications where failure of this equipment can reasonably be expected to cause the failure of the life support equipment or to significantly affect its safety or effectiveness is not recommended.

FCC Notice, Class B

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications to this equipment not expressly approved by Tripp Lite could void the user's authority to operate this equipment.

WEEE Compliance Information for Tripp Lite Customers and Recyclers (European Union)



Under the Waste Electrical and Electronic Equipment (WEEE) Directive and implementing regulations, when customers buy new electrical and electronic equipment from Tripp Lite they are entitled to:

- Send old equipment for recycling on a one-for-one, like-for-like basis (this varies depending on the country)
- Send the new equipment back for recycling when this ultimately becomes waste

Tripp Lite has a policy of continuous improvement. Specifications are subject to change without notice. Photos and illustrations may differ slightly from actual products.



1111 W. 35th Street, Chicago, IL 60609 USA • triplite.com/support