

**Warranty
Registration:**
register online today for a
chance to win a FREE Tripp Lite
product—www.tripplite.com/warranty



Smart IP Access

User Guide



1111 W. 35th Street, Chicago, IL 60609 USA
www.tripplite.com/support

Copyright ©2012 Tripp Lite. All rights reserved.

Table of Contents

1. Welcome	3
2. Introduction	4
3. Key Features	4
4. System components.....	4
5. The Smart IP Access unit.....	5
6. Pre-installation guidelines	6
6.1 Avoiding general rack mounting problems	6
6.2 Rack mounting the IP Access.....	7
7. Terminology	7
8. Client computer operating system.....	8
9. Connecting the system	8
10. Default IP address.....	10
11. Logging into the Web interface	11
11.1 SSL Certificate notes.....	12
12. Network > Configuration	12
12.1 LAN 1	12
12.2 KVM.net	13
13. Network > SNMP settings	13
14. Administration > User Settings	14
14.1 Administrator	14
14.2 User.....	14
14.3 View only	14
14.4 Adding a user.....	15
14.5 Editing a user	16
14.6 Deleting a user	16
14.7 Blocking a user	16
15. Administration > Switch configuration.....	16
16. Administration > Serial Settings	17
16.1 Show	18
17. Security > Settings	18
18. Security > SSL certificates.....	19
19. Security > Event Log	20
20. Maintenance > Set System Time	20
21. Maintenance > Firmware Upgrade	21
22. Maintenance > Restore Factory Settings	21
23. Saving changes and logging out	22

24. Starting a remote session 22

24.1 Taking over a busy remote session 23

24.2 Full screen mode 23

24.3 Moving or hiding the Toolbar..... 24

24.4 Switching to a different server/device 24

24.5 Changing the performance settings..... 25

24.6 Adjusting the Video settings..... 26

 24.6.1 Refresh 26

 24.6.2 Manual Video Adjust 26

 24.6.3 Auto Video Adjust 27

24.7 Power cycle 27

24.8 Keyboard key sequences..... 27

24.9 Synchronizing mouse pointers..... 29

 24.9.1 Aligning the mice pointers 29

 24.9.2 Calibrating mice pointers..... 29

 24.9.3 Manual mice synchronization 30

24.10 Minicom logo menu features 31

24.11 Disconnecting the remote session..... 32

25. Troubleshooting - Restoring factory defaults..... 32

26. Technical Specifications 35

27. Video Resolution and Refresh Rates 36

28. Safety 36

29. User Guide Feedback Error! Bookmark not defined.

30. WEEE Compliance 37

1. Welcome

Thank you for buying the Smart IP Access system. This system is produced by Minicom Advanced Systems Limited.

This document provides installation and operation instructions for Minicom's Smart IP Access. It is intended for system administrators and network managers, and assumes that readers have a general understanding of networks, hardware and software.

Technical precautions

This equipment generates radio frequency energy and if not installed in accordance with the manufacturer's instructions, may cause radio frequency interference.

This equipment complies with Part 15, Subpart J of the FCC rules for a Class A computing device. This equipment also complies with the Class A limits for radio noise emission from digital apparatus set out in the Radio Interference Regulation of the Canadian Department of Communications. These above rules are designed to provide reasonable protection against such interference when operating the equipment in a commercial environment. If operation of this equipment in a residential area causes radio frequency interference, the user, and not Minicom Advanced Systems Limited, will be responsible.

Changes or modifications made to this equipment not expressly approved by Minicom Advanced Systems Limited could void the user's authority to operate the equipment.

Minicom Advanced Systems Limited assumes no responsibility for any errors that appear in this document. Information in this document is subject to change without notice.

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Minicom Advanced Systems Limited.

Trademarks

All trademarks and registered trademarks are the property of their respective owners.

2. Introduction

The Smart IP Access extends your KVM (keyboard, video, mouse) from any computer or server over TCP/IP via LAN, or WAN. Now you can control, monitor and manage your servers from wherever you are, inside or outside the organization. The Smart IP Access is a cost-effective hardware solution, for secure remote KVM access & control of a computer/server from the BIOS level - independent of the OS. It is designed to connect to a single computer or to a KVM switch to access multiple servers, over TCP/IP communication.

3. Key Features

BIOS level access to any server's brand and model, regardless of the server condition and network connectivity, covering the entire spectrum of crash scenarios.

Low bandwidth requirement. Provides a unique ability to utilize a standard 56Kbps analog modem connection, while allowing adaptive and configurable bandwidth consumption when accessed via LAN.

Compatible with all major operating systems. Supports many hardware and software configurations for the remote client and the target server computers, as well as the KVM switch in use.

Web-based Access - Browser access to a target server, from any location via secured standard IP connection.

SNMP - SNMP traps for monitoring Smart IP Access events and operation.

Multi-user view mode - Allows simultaneous users to view remote sessions. Remote control can be intuitively handed between users with appropriate permissions.

4. System components

The Smart IP Access system consists of:

- 1 Smart IP Access (p/n 1SU51068)
- 3 in 1 CPU cable (p/n 5CB10477)
- 1 RS232 Cross cable (p/n 5CB00566)
- Rack-mount kit (p/n 5AC20255)

The RS232 Cross cable connects the Smart IP Access to Serial manageable devices such as Power Management units, Routers, etc.

RS232 Cross cable option

Smart IP Access has two RS232 RJ45 connectors. You can purchase another RS232 Cross cable to connect a second Serial device. P/N 5CB00566

5. The Smart IP Access unit

Figure 1 illustrates the front panel of the Smart IP Access.



Figure 1 Smart IP Access front panel

The table below lists the LEDs, buttons and functions.

LED/Button	Function
Power	Power Indicator
Remote	Illuminates when remote session is active
Local	When pressed, Smart IP Access disconnects the Client computer's link to the Target Server, and the Local Mouse and Keyboard become operational.
Reset	Restarts the Smart IP Access unit

The figure below illustrates the rear panel of the Smart IP Access.




Figure 2 Smart IP Access rear panel

The table below lists the rear connectors and functions.

Connector	Function
Computer KVM	Connect a computer or KVM switch
Console KVM	Connect a keyboard, video and mouse to operate the Smart IP Access locally
Serial 1 and 2 RS232	Connect to an RS232 device
LAN 1 and 2	Connect to 10/100 Mbit Ethernet

6. Pre-installation guidelines

Place cables away from fluorescent lights, air conditioners, and machines that are likely to generate electrical noise.

Place the Smart IP Access on a flat, clean and dry surface.

The Smart IP Access is not intended for connection to exposed outdoor lines

6.1 Avoiding general rack mounting problems

Elevated operating ambient temperature

The operating ambient temperature of the rack environment may be greater than the room ambient when installing into a closed or multi-unit rack assembly. So install the equipment in an environment compatible with the maximum rated ambient temperature.

Reduced airflow

Install the equipment in a rack in such a way that the amount of airflow required for safe operation is not compromised. Leave a gap of at least 5cm/2” each side of the Smart IP Access.

Mechanical loading

Mount the equipment in the rack in such a way that a hazardous condition is not achieved due to uneven mechanical loading.

Circuit overloading

When connecting the equipment to the supply circuit, consider the effect that overloading of circuits might have on over-current protection and supply wiring.

Reliable earthing of rack-mounted equipment should be maintained. Give attention to supply connections other than direct connections to the branch circuit (e.g. use of power strips).

6.2 Rack mounting the IP Access

Rack mount the Smart IP Access using the supplied Rack-mount kit. There are 2 possible positions on the side of the Smart IP Access to connect the bracket. Screw the bracket to the Smart IP Access using 2 screws. See Figure 3. Screw the other bracket section to the rack.




Figure 3 Rack mounting the Smart IP Access

7. Terminology

Below are some terms and their meanings used in this guide.

Term	Meaning
Target Server	The computers/servers that are accessed remotely via the Smart IP Access.
Client computer	The PC running a remote Smart IP Access session
Remote Session	The process of accessing and controlling Target Servers connected to Smart IP Access from a User station

8. Client computer operating system

Windows NT4.0, 2000, XP or 2003 Server, with IE 6.0 or higher. 128 bit encryption is required if a secured connection is selected.

9. Connecting the system

Connect the Target Server / KVM switch to the Smart IP Access as follows:

1. Connect one end of the 3 in 1 CPU cable to the **Computer** ports of the Smart IP Access.
2. Connect the other end of the 3 in 1 CPU cable to the KVM ports of the Target Server / KVM switch.
3. To operate the KVM switches and Servers locally, connect a keyboard, mouse and monitor to the IP Access's Local Console connectors.
4. Connect Smart IP Access to the network by attaching one of the LAN ports to an Ethernet port on your Network. IP Access has two LAN interfaces – see Initial Settings
5. Connect to the power supply using the power cord provided.

Figure 4 and Figure 5 illustrate the connections to a computer and KVM switch respectively, with the optional KVM console.




Figure 4 Smart IP Access connections to a computer




Figure 5 Smart IP Access connections to a KVM switch

10. Default IP address

Smart IP Access has two available Ethernet Adapters, **LAN 1** and **LAN 2**:

- By default, **LAN 1** boots with an automatically assigned IP address if a DHCP (Dynamic Host Configuration Protocol) server exists. The MAC address appears on a label on the underside of the IP Access box. Also on the label is the 6-digit device number (D.N.). The default device name is the letter 'D' followed by the device number

- **LAN 2** boots with the default IP configuration:

IP Address - 192.168.0.155

Subnet mask - 255.255.255.0

You can use the default Smart IP Access IP address if your computer resides on the same subnet where Smart IP Access is installed, or you can connect a Crossover LAN connector cable to the Smart IP Access on one end, and to the Ethernet adapter of your computer at the other end.

11. Logging into the Web interface

To complete the initial setup via the Web configuration interface:

1. Open your Web browser (Internet Explorer version 6.0 or higher)
2. Type the IP address of the Smart IP Access system - `https://IP address/config` and press **Enter**. The login page appears, see Figure 6




Figure 6 Login page

3. Type the Administrator user name and password. By default, the user name is: **admin** and the password is **access** (both lower case).
4. Press **Enter**. The Web interface opens at the Network Configuration page. See Figure 7.
5. Bookmark the page for easy reference.




Figure 7 Smart IP Access Web interface

11.1 SSL Certificate notes

Upon first connection to Smart IP Access's https Configuration page, 2 browser security warnings appear. Click **Yes** to proceed.

The first warning disappears upon first Smart IP Access client installation, once Minicom's root certificate is installed.

12. Network > Configuration

Consult your Network Administrator for the network settings.

Device name - Type the name for the Smart IP Access. Default device name consists of the letter 'D' followed by the 6-digit device number (D.N.) found on the silver label on the underside of the IP Access box.

First TCP Port - Choose 3 consecutive ports, and type in the first port number of the series. The default port – 900 – is suitable for the majority of installations.

Note

Firewall or router security access list must enable inbound communication through the selected TCP ports for the Smart IP Access's IP address.

For Client computer access from a secured LAN, the selected ports should be open for outbound communication.

Enable Encryption - Enable Encryption if you wish to operate in a secure connection (recommended).

If enabled, the Internet Explorer at the Client computer must support 128 bit Encryption.

Force HTTPS - Access the Web front-end only using an HTTPS connection. Smart IP Access won't listen on the HTTP port for incoming connections.

12.1 LAN 1

Under LAN 1 in Figure 7, is the following:

Enable DHCP – When a DHCP server is active on the same network to which Smart IP Access is connected, DHCP provides automatic IP assignment.

When DHCP is disabled – (Recommended) – You can assign a fixed IP address to the Smart IP Access.

Consult your Network Administrator regarding the use of the DHCP. **Note!** Where you have access to the DHCP server– your configured (or default) Smart IP Access device name will appear on the DHCP server's interface, making it easy to locate.

Enable Access for Configuration - Click to enable access to the configuration menu from the **LAN 1**. If disabled, a remote session can only be performed via **LAN 1** and the Web configuration menu can only be accessed from **LAN 2**. This may be useful when dedicating **LAN 2** to LAN access only, to enhance security.

When DHCP is disabled, enter an **IP Address**, **Subnet Mask**, and **Default Gateway** for **LAN 1** and **2**, as given by your Network Administrator.

12.2 KVM.net

KVM.net is a centralized IP based system for secure control of servers and network devices, power and user administration in the data center environment.

KVM.net combines Out-Of-Band, KVM via IP access with modern IT standards and requirements. It is the most comprehensive remote server maintenance solution available in the market today.

Enable KVM.net - Check this option to allow Smart IP Access unit to be remotely managed by Minicom's **KVM.net** system.

Manager Auto Discovery – when checked, **KVM.net** automatically detects Smart IP Access, if it resides on the same network segment.

Manager IP – If Smart IP Access resides on a different segment, type the static IP address of the KVM.net Manager. (We advise typing the static IP address of the KVM.net Manager even if the Smart IP Access resides on the same network segment as the KVM.net Manager).

13. Network > SNMP settings

From the menu click SNMP settings. The following appears.

SNMP:

Enable traps:	<input type="checkbox"/>
Community:	<input type="text" value="kvm.net"/>
SNMP Manager IP:	<input type="text" value="0 . 0 . 0 . 0"/>

Figure 8 SNMP settings

From this page you can activate or deactivate SNMP logging.

Enable traps - Check to enable SNMP traps of Smart IP Access events and operation.

Community – type the SNMP community.

SNMP Manager IP - Enter the SNMP Server IP address.

14. Administration > User Settings

From the menu click User Settings, the following appears.

Administration > User Settings

User: Password: Block:

Permission: Administrator Confirm Password:

User	Permission	Status
1. admin	Administrator	

MINICOM

Figure 9 User Settings

On this page an Administrator creates and edits users.

There are 3 levels of user access.

- Administrator
- User
- View only

14.1 Administrator

An Administrator has unrestricted access to all windows and settings and can “take over” any active session. An Administrator can change the name and password of all users.

14.2 User

A User has no access to the Web configuration interface. When accessing a Target Server a User cannot use the following:


- Advanced mouse settings
- Power cycle

14.3 View only

View only can view the screen of any Target Server without keyboard and mouse control. Only limited options appear such as switching Servers and Disconnect (Explained on pages 24 and 32). A “view only” indicator appears on the viewer’s local mouse pointer.


14.4 Adding a user

To add a user:

1. Click  and type a name and a password. The password must be at least 6 characters – letters or numbers, and must not include the user name, even if other characters are added.



Note! The following “special” characters: &, <, >, ”, {, } cannot be used for either the user name or password.

Depending on the security level chosen the user name and password parameters are different. See section 17 on page 18.

2. Select the permission type from the **Permission** box.
3. Click , the user appears in the list of users.



14.5 Editing a user

To edit a user:

1. Select the user from the list.
2. Click . You can now change all the parameters – user name, permission and password.
3. Click , the changes are saved.

14.6 Deleting a user

To delete a user:

1. Select the user from the list.
2. Click .
3. Click , the changes are saved.

14.7 Blocking a user

An alternative to deleting a user is blocking a user. This means that the user's name and password is stored, but the user is unable to access the system. Check **Block** to block a user. Uncheck **Block** to allow the user access.

15. Administration > Switch configuration

When a KVM switch is connected to the system, you must configure the switch in the system.

To do so:

1. From the menu click **Switch Configuration**. The KVM Switch Configuration window appear, see Figure 10.

Administration > Switch Configuration

Manufacturer:

Model:

Server Name

1	<input type="text" value="Server1"/>	9	<input type="text" value="UNUSED"/>
2	<input type="text" value="UNUSED"/>	10	<input type="text" value="UNUSED"/>
3	<input type="text" value="UNUSED"/>	11	<input type="text" value="UNUSED"/>
4	<input type="text" value="UNUSED"/>	12	<input type="text" value="UNUSED"/>
5	<input type="text" value="UNUSED"/>	13	<input type="text" value="UNUSED"/>
6	<input type="text" value="UNUSED"/>	14	<input type="text" value="UNUSED"/>
7	<input type="text" value="UNUSED"/>	15	<input type="text" value="UNUSED"/>
8	<input type="text" value="UNUSED"/>	16	<input type="text" value="UNUSED"/>

Install Switch Definition File

MINICOM

Figure 10 Switch configuration

1. Choose the manufacturer and model of the connected KVM switch. The number of possible connected servers appears in the **Server Name** section.
2. Change the name of the connected servers by selecting the server and typing a new name. Click to save changes.

Note! Server names left as **UNUSED** cannot be accessed.

Install switch definition file

Where the KVM switch type is not listed in the manufacturer/model drop-down lists, contact Minicom to request an updated Switch Definition file with the desired KVM switch listed.

1. Load the file onto the Client computer.
2. Locate and install the KVM switch definition file. The switch definition file is updated.

16. Administration > Serial Settings

Where you have a Serial device connected to the system you must configure the RS232 settings.

To do so:

From the menu click **Serial Settings**, the **Serial Settings** appear, see Figure 11.

Serial Port 1

Device Name:

Baud Rate: Data Bits:

Parity: Stop Bits:

Show:

Serial Port 2

Device Name:

Baud Rate: Data Bits:

Parity: Stop Bits:

Show:

MINICOM

Figure 11 Serial Settings

For both Serial ports (where relevant), type in a device name and choose the correct device parameters.

16.1 Show

Tick **Show** to make the device appear in the list of servers/devices that can be accessed. Where there is no device connected to the particular Serial port uncheck **Show**.

17. Security > Settings

Configure the security features, such as Account Blocking, Password Policy and Idle Timeout, as explained below.

From the **Security** section click **Settings**, the **Security Settings** appear, see Figure 12.

Security > Settings

Account Blocking

Block after attempts within H M

Block account for H M forever

Password Policy

High security password policy

Idle Timeout

Disconnect after min. of inactivity

MINICOM

Figure 12 Security Settings

The security page elements:

Account Blocking – decide on the number of attempts to login with a wrong username or password after which there is a time lock or a total block.

Password Policy – You have the option of a standard or high security level of password. The table below shows the parameters of the 2 options.

Standard Security Password	High security Password
6 characters or more	8 characters or more must include at least 1 digit and 1 upper case letter and 1 “special” character as follows !@#%&^*()_+=[\]';:;/
Must not include the user name	Must not include the user name

Check the box to enable the high security password policy. Unchecked, the standard security policy applies.

Idle Timeout – Select the Timeout inactivity period after which the user is disconnected from the system. Timeout can also be disabled.

18. Security > SSL certificates

From the menu, select **SSL Certificate**, the SSL Certificate page appears, see Figure 13.

The screenshot shows the 'SSL Certificate' configuration page. At the top right, the breadcrumb 'Security > SSL Certificate' is visible. Below it, there is a red button labeled 'Install SSL Certificate'. The main form area has a light gray background and contains three fields: 'Certificate File:' with a text input and a 'Browse...' button, 'Private File:' with a text input and a 'Browse...' button, and 'Key Password:' with a text input field.

Figure 13 The SSL Certificate page

You can replace the current Smart IP Access’s SSL certificate.

Certificate File - Browse to locate the **cer** file.


Private File - Browse to locate the **private key** file.

Key Password - Type the “private key” password.

Click **Save & Restart**.

19. Security > Event Log

From the menu select **Event Log**. The Event Log page appears, see Figure 14. Here you can view the device log, recording various events: security alerts, system alerts, configuration changes, and user activity.



Maintenance > Device Log


Device Log

Date	Action	User	Severity	Details
Wed, 23 Mar 2005 16:58:52	(2010) Config: User login succeeded	admin		PeerIP = 192.168.0.148
Wed, 23 Mar 2005 16:58:52	(2010) Config: User login succeeded	admin		PeerIP = 192.168.0.148
Wed, 23 Mar 2005 12:16:04	(2010) Config: User login succeeded	admin		PeerIP = 192.168.0.148
Wed, 23 Mar 2005 12:16:04	(2010) Config: User login succeeded	admin		PeerIP = 192.168.0.148
Wed, 23 Mar 2005	(2010) Config: User login succeeded	admin		PeerIP = 192.168.0.148

Figure 14 Event log

20. Maintenance > Set System Time

From the menu select **Set System Time**. The Time Settings page appears see Figure 15. Set the correct date and time for Smart IP Access so that the logs record the correct time of the events.



Maintenance > Set system time

Time settings

Date: D: M: Y:

Time: H: M: S:

MINICOM

Figure 15 Time Settings

21. Maintenance > Firmware Upgrade

Upgrade the Smart IP Access firmware to take advantage of new features. You can receive firmware updates by email or download them from the Minicom Web site. Save the firmware file on the Client computer.

From the menu select **Firmware Upgrade**. The Firmware Upgrade page appears see Figure 16.




Figure 16 Firmware Upgrade page

1. Locate and install the firmware file.
2. Click **Start Upgrade**. The upgrade starts. On completion, click **Reboot**. The unit reboots. After about 30 seconds the Login page appears.

Notes

(a) When KVM.net is enabled (in the Configuration page see page 13), all firmware upgrades are done via KVM.net.

(b) Depending on the type of firmware upgrade, the following settings may be erased: User settings, KVM switch settings, mouse and video adjustments and RS232 settings. For more information refer to the firmware release notes. The network settings remain intact.

22. Maintenance > Restore Factory Settings

You can restore the Smart IP Access system to the factory settings. This restores the original Smart IP Access parameters, resetting all the information added by the administrators, including: Network settings, Servers, Switches, Users, Passwords etc.

Warning! Once reset the data cannot be retrieved.

To restore factory settings:

1. From the menu select **Restore Factory Settings**. Restore Factory Settings appears see Figure 17.




Figure 17 Restore factory settings

2. Click

23. Saving changes and logging out

To save any configuration changes and restart the IP Access click .

To exit the configuration menu and close the session click .

Only one Administrator can log into the configuration area at a time. An idle timeout of 30 minutes terminates the session.

24. Starting a remote session

At a Client computer open Internet Explorer (6.0 and above) and type the Smart IP Access's IP address. `https://IP address`. The Login box appears. Type your username and password and press Enter. By default, the user name is: **admin** and the password is **access**, (both lower case).

On first connection install the Minicom certificate and ActiveX control.

The screen of the Target Server connected directly to Smart IP Access, or the currently selected server on the KVM switch with Smart IP Access toolbar appears see Figure 18.




Figure 18 Remote session window

24.1 Taking over a busy remote session

When connecting to a busy Target Server an Administrator has the option to take over the Target Server. A User only has this option when the current session is run by another User, but not by an Administrator. The following message appears



Figure 19 Busy remote session options

Choose to take over or view only or cancel.

24.2 Full screen mode

Work on the Target Server as if you are working on a local computer, with full screen mode.

To work in full screen mode:

1. Ensure that the Client computer has the same screen resolution as the Target Server.
2. Press **F11**. The Internet Explorer window disappears, leaving the Internet Explorer menu bar at the top.

3. Right click the Internet Explorer menu bar and check Auto-Hide. The Internet Explorer menu bar disappears. You are in full screen mode.


To exit full screen mode:

Press **F11**. Or place the mouse at the top of the window to display the Internet Explorer toolbar and click the Restore button.

Note! Full screen mode can also be activated from the Toolbar menu, see page 32.

24.3 Moving or hiding the Toolbar

The Toolbar can be dragged and dropped to anywhere on the screen, by clicking

and dragging the logo .

To hide the Toolbar, either:


Double-click the Smart IP Access System tray Icon .

Or

Press **F9**.



To display the Toolbar repeat the above actions. See also page 32.

To minimize the Toolbar:

Click the arrow . Click again to maximize the Toolbar.

24.4 Switching to a different server/device

To connect to a different server/device:

1. From the Toolbar, click , or right-click . A list of connected servers/devices appears.
2. Click the desired server or Serial device. The screen of the server or the Serial device window appears.

24.5 Changing the performance settings

You can alter the bandwidth settings from the Toolbar.

To alter the settings:

From the Toolbar, click . The Settings.. box appears, see Figure 20.




Figure 20 Settings.. box

Bandwidth

Choose from the following options

Adaptive – automatically adapts to the best compression and colors.

Low - Select Low for high compression and 16 colors.

Medium - Select medium for medium compression and 256 colors. Medium is recommended when using a standard internet connection.

High - For optimal performance when working on a LAN, select High. This gives a low compression and high colors (16bit).

Custom – You can choose your own compression and color levels.

Click **OK**. The screen of the last accessed Target Server appears.

24.6 Adjusting the Video settings

To change the video settings:

From the Toolbar, click . You have the following options:

- Refresh
- Manual Video Adjust
- Auto Video Adjust

Each option is explained below.

24.6.1 Refresh

Select Refresh or press **Ctrl+R** to refresh the Video image. Refresh may be needed when changing the display attributes of a Target Server.

24.6.2 Manual Video Adjust

Use the manual video adjustment for fine-tuning the Target Server video settings after auto adjustment or for adapting to a noisy environment or a non-standard VGA signal or when in full-screen DOS/CLI mode.

To adjust the video manually:

1. Click Manual Video Adjust. A slider bar appears. See Figure 21. Also a red frame appears around the screen. This represents the screen area according to the Server's screen resolution. Perform the adjustments inside and relative to this frame.



Figure 21 Manual Video Adjustments controls

2. Move the sliders to change the displayed image. Click in the area of the sliders for fine-tuning.

Brightness / Contrast - use the scales to adjust the brightness and contrast of the displayed image.

Horizontal Offset - defines the starting position of each line on the displayed image.

Vertical Offset - defines the vertical starting position of the displayed image.

Phase - defines the point at which each pixel is sampled.

Noise Level - represents the Video "noise" when a static screen is displayed.

Automated adjust – When checked, the video adjusts automatically whenever there is a change in the screen resolution.

24.6.3 Auto Video Adjust


To adjust the video automatically:

We recommend opening Windows Explorer (or similar) in the background.


Click **Auto Video Adjust**. The process takes a few seconds. If the process runs for more than 3 times, there is an abnormal noise level. Check the video cable and verify that no dynamic video application is running on the Target Server's desktop.

Perform the procedure where necessary for each Target Server or new screen resolution.

24.7 Power cycle

Power cycle button . This option is currently unavailable.

24.8 Keyboard key sequences

Click . A list of defined keyboard sequences appears. When clicked, these transmit directly to the Target Server, and will not affect the Client computer.

For example, select **Ctrl-Alt-Del** to send this three key sequence to the Target Server to initiate its Shutdown/Login process.

To add a keyboard sequence:

Click **Add/Remove**. The Special Key Manager box appears see Figure 22.




Figure 22 Special Key Manager box

To add a predefined sequence:

1. Click Add Predefined. A list of sequences appears.
2. Select the desired sequence and click OK. The sequence appears in the Special Key Manager box.
3. Click OK. The sequence appears in the Keyboard Key sequence list.

To record a key sequence:

1. From the Special Key Manager box press **Record New**. The Add Special Key box appears see Figure 19.




Figure 23 Add Special Key box

2. Give the key sequence a name in the Label box.
3. Click **Start Recording**.
4. Press the desired keys. The keys appear in the area provided.
5. Click **Stop Recording**.
6. Click **OK**.

To edit a key sequence:

1. From the Special Key Manager box select the desired key.
2. Click **Edit**.
3. Click **Start Recording**
4. Press the desired keys. The keys appear in the area provided.
5. Click **Stop Recording**.
6. Click **OK**.

24.9 Synchronizing mouse pointers

When working at the Client computer, two mouse pointers appear: The Client computer's is on top of the Target Server's. The mouse pointers should be synchronized. The following explains what to do if they are not synchronized.


Warning

Before synchronizing mouse pointers adjust the video of the Target Server, (explained above) otherwise mouse synchronization may not work..

24.9.1 Aligning the mice pointers

When accessing the Target Server, the mice may appear at a distance to each other.


To align the mouse pointers:

From the Toolbar click  / **Align** or press **Ctrl+M** simultaneously. The mice align.

24.9.2 Calibrating mice pointers

A Target Server may have a different mouse pointer speed to the Client computer. Calibrating automatically discovers the mouse speed of the Target Server and aligns the two pointers.

To perform the calibration when the Target Server Operating system is, Windows NT4, 2000 or 98:

From the Toolbar click  / **Calibrate**. Smart IP Access saves this alignment so calibration is only needed once per Target Server.

If the Video Noise Level is above zero, calibration may not work. Go to Video Adjustment and try to eliminate the noise by pressing Auto video adjust and/or adjusting the bars in Manual video adjust, then perform the mouse calibration.

Note! If the mouse settings on the Target Server were ever changed, you must synchronize mouse pointers manually, as explained below.

24.9.3 Manual mice synchronization

If the mouse settings on the Target Server were ever changed, or when the Operating system on the Target Server is, Windows XP / 2003 Server / Vista, Linux, Novell, SCO UNIX or SUN Solaris you must synchronize the mouse pointers manually.

To manually synchronize mouse pointers:

1. From the Toolbar click  / **Manual Settings**. The **Mouse Settings** box appears see Figure 24.





Figure 24 Mouse Settings box

2. Select the Target Server's Operating System and click OK. Instructions and sliders appear.
3. Follow the instructions and set any relevant sliders to the same values as set in the Target Server's Mouse Properties window.

2 examples!

For Windows XP, go to the Mouse settings on the Target Server and uncheck Enhance pointer precision.

For Windows NT4. If Mouse Properties were ever changed for the Target Server – even if they have been returned to their original state - uncheck default -  Default


Click **OK**. The mouse pointers should be synchronized.

USB

The USB option in Mouse Settings box is available for RICC and X-RICC USB and Phantom Specter USB and for unsupported operating systems and SUN Solaris. Use this option if you are sure of the custom acceleration algorithm you are using, or have been informed so by customer support.

Advanced – Mouse Emulation

In the Advanced Mouse settings, you can set the type of mouse that you would like Smart IP Access to emulate. We recommend not changing the advanced settings unless there is erratic mouse behavior (the mouse is making random clicks and jumping arbitrarily around the screen).

Click  the Mouse Emulation box appears see Figure 25.




Figure 25 Mouse Emulation box


Select the mouse connected to the Local Console port on the Smart IP Access, e.g. if the local mouse is a non-Microsoft 2 button mouse, select **Standard Mouse** and uncheck **Microsoft Mouse**.

Switch Acceleration - In some KVM switch brands (for example G&D, Rittal), the switch accelerates the mouse on top of the acceleration provided by the operating system. If necessary, check this option to compensate (decelerate) the switch acceleration and achieve full synchronization.

Max Rate - this defines the maximum mouse report rate. For Sun Solaris the default value is 20 in order to support older Sun versions.

24.10 Minicom logo menu features



Right click the Minicom logo , a menu appears. From this menu you can access the connected devices. You also have the following features:

Disconnect – You can disconnect the session by clicking Disconnect.

About - Click About to verify the Client, Firmware, KME (Keyboard/Mouse Emulation firmware) and Switch file versions installed on your Smart IP Access.

Local Settings – Click Local settings, the Client Configuration box appears, see Figure 26





Figure 26 Client Configuration box

Pointer type – From the Drop-down menu you can change the Client computer mouse pointer to appear as a dot or to not appear at all.

Hide Toolbar – Check this option to hide the Toolbar from the next reconnection onwards. To toggle the Toolbar on and off, press **F9**. See above page 24.

Full Screen Mode - Check this option to make the remote session screen appear in full screen mode from the next reconnection onwards. To toggle the full screen mode on and off, press **F11**.

24.11 Disconnecting the remote session

To disconnect the session, on the Toolbar, click . The Login box appears. You can re-login or close the browser window.


25. Troubleshooting - Restoring factory defaults

Section 22 on page 21 explained how to restore factory settings from the Web interface. When you cannot access the system e.g. you have forgotten the Username or Password, you can restore factory defaults from the Smart IP Access unit.

To restore factory defaults:

1. Switch on the unit.
2. Within 3 seconds of switching on, press and keep holding down the Local button.
3. Press and release the Reset button. The Remote LED illuminates.
4. While the Remote LED illuminates, release the Local Button then re-press it and immediately release it. The Remote LED turns off.

5. Wait 2 minutes until the unit finishes booting.
6. Connect the lower network interface (**LAN 2**) to the network, and login with the default IP address of the unit: <http://192.168.0.155/config>. The Login box appears see Figure 27.



User:

Password:

Login

Figure 27 Login box

7. Type username: **admin** , password: **SAFEmode**. (Case sensitive). This username and password works only after the reset procedure described above. A menu appears, see Figure 28.



Firmware Upgrade
Restore Factory Settings
Log Out
Save and Restart

Figure 28 Menu

8. From the menu choose **Restore Factory Settings**. A warning appears see Figure 29.




Warning:

All device data will be lost!
Are you sure?

Restore **Back**

Figure 29 Restore factory settings

9. Click **Restore**. The factory defaults are restored and all user data, switch configurations, user names and passwords are erased. When the process finishes Figure 30 appears.




Restore succeeded!

Reboot

Figure 30 Reboot

10. Click **Reboot** to restart the unit. The following message appears.



System is restarting:

Please wait

Figure 31 System restarting

11. Wait for 2 minutes and then type the default configuration IP address of the unit: <https://192.168.0.155/config> into your web browser. The Login page appears as in Figure 6 on page 11.
12. Type the default Administrator user name and password. Username: **admin**, password: **access**. (Case sensitive).
13. Configure the unit according to your network settings, see page 12. Create new users and change the Administrator's password in the User Settings, see page 14.

26. Technical Specifications

Operating systems	<p>Target Server Windows 3.1, 9X, 2000, XP, NT4, 2003 Server, Vista. DOS, Novell 3.12 – 6, Linux</p> <p>Client Computer Windows NT4.0, 2000, XP or 2003 Server, with IE 6.0 or higher</p>
Resolution	<p>Target Server Up to 1600x1200 @85Hz</p> <p>Client Computer Recommended - resolution should be higher than on Target Server</p>
Video and mouse synchronization	Both auto and manual modes
Connections	<p>Ethernet – 2 X RJ45 – 10/100 Mbit/sec autosensing</p> <p>Serial – 2 X RJ45</p> <p>Local KVM connection – Screen HDD15, Keyboard./Mouse – MiniDIN6</p> <p>Computer / switch connection – Screen HDD15, Keyboard./Mouse – MiniDIN6 3 in 1 cable 1.8m</p>
Weight	1.204kg/ 2.65lbs
Dimensions (H x D x W)	44 X 230 X 215mm / 1.7 x 9 x 8.5in
Power supply	100-240 VAC, 50/60 Hz, 0.24 A
Operating temperature	0°C to 40°C / 32° to 104°F
Storage temperature	-40°C to 70°C/-40°F to 158°F
Humidity	80% non condensing relative humidity

27. Video Resolution and Refresh Rates

Hz →	56	60	65	66	70	72	73	75	76	85	86
640x480		x		x	x	x		x		x	
720x400					x					x	
800x600	x	x				x		x		x	x
1024x768		x			x	x	x	x	x	x	
1152x864								x			
1152x900				x					x		
1280x720		x									
1280x768		x						x			
1280x960		x								x	
1280x1024		x				x		x	x	x	
1600x1200		x	x		x			x		x	

28. Safety

The device must only be opened by an authorized Minicom technician. Disconnect device from AC mains before service operation!

Caution

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

29. WEEE Compliance

WEEE Information for Minicom Customers and Recyclers

Under the Waste Electrical and Electronic Equipment (WEEE) Directive and implementing regulations, when customers buy new electrical and electronic equipment from Minicom they are entitled to:

- Send old equipment for recycling on a one-for-one, like-for-like basis (this varies depending on the country)
- Send the new equipment back for recycling when this ultimately becomes waste

Instructions to both customers and recyclers/treatment facilities wishing to obtain disassembly information are provided on our website www.minicom.com.

