

LX Firmware Update Instructions

This document provides instructions on updating LX Platform firmware, as performed through the LX device interface. Note that the sequence of steps and referenced file names also apply to updating LX Platform firmware using PowerAlert® Mass Updater v1.1.1. This document is divided into two sections:

Section 1—Updating LX Platform devices running firmware version 15.00 or firmware version 15.02.


Section 2—Updating LX Platform devices running firmware version 15.04 or later.

To verify which update process to follow, click **About** in the device's web interface to view the PowerAlert Engine Version.

If the Engine version begins with 15.00 or 15.02, proceed to Section 1.

If the Engine version begins with 15.04 or 15.5.x, proceed to Section 2.

Warning: Executing the update with the wrong file or in the wrong sequence may place the device into a state where it cannot accept a firmware update.




The screenshot displays the 'About' page of the PowerAlert Device Manager. The left sidebar contains a menu with items: Status, Control, Configuration, Logs, About, and Active Alarms. The 'About' item is highlighted with a green arrow. The main content area shows a table of system information:

Item	
Operating System	Ubuntu 16.04.2 LTS Linux 4.4.31 flash: 3.5G ram: 247204kB processor: a...
Agent Type	Nmc5
MAC Address	00:06:67:40:2F:D3
Serial Number	2720FV0AC88E200919
PowerAlert Driver Version	15.04.0000.16301.0001
PowerAlert Console Version	15.04 (16301M-0001)
PowerAlert Engine Version	15.04 (16301M-0001)
Driver File Status	Normal
SNMP v3 Engine ID	8000035203000667402fd3



1. Update for Devices Running Firmware Versions 15.00 or 15.02


- 1 In the interface menu, click **Control > Device**, then select the **Firmware Update** check box. The **Choose File** button will appear below the Control menu.



- 2 Click the **Choose File** button. In the window that appears, navigate to the location where the downloaded Firmware folder is stored. From within the STEP 1 folder, select the **Repo_padm_upgrade_15_0_step1-15.5.3.16000.tar** file, then click **Open**. The window will close and return to the device web interface.





If using the PowerAlert Mass Updater utility (version 1.1.1 or later), click the **Browse** button and navigate to the location where the downloaded Firmware folder is stored. Select the STEP 1 folder, then click **OK**.



1. Update for Devices Running Firmware Versions 15.00 or 15.02


- 3 Click the Run Control button  to start the update procedure. A message box will appear, asking to confirm starting the update. Click **Continue**. Please allow several minutes for the update to complete.




- 4 When the update is complete, clear the browser cache. Close, then reopen the browser and log in to the device's web interface.

1. Update for Devices Running Firmware Versions 15.00 or 15.02

- 5 Repeat steps 1 through 4, this time opening the STEP 2 folder and selecting the **Repo_padm_upgrade_15_0_step2-15.5.3.1031.tar** file. Please wait at least 10 minutes for this update to complete.




If using the PowerAlert Mass Updater utility (version 1.1.1 or later), click the **Browse** button and navigate to the STEP 2 folder. Select it, then click **OK**.




- 6 When the second upgrade has been completed, go to the **About** page to confirm the update was successfully installed.

Note: If the device had a dynamically assigned (DHCP) IP address, the IP address may be different after the upgrade.




2. Update for Devices Running Firmware Version 15.04 or 15.5.x

- 1 In the interface menu, click **Control** > **Device**, then select the **Firmware Update** check box. When the Update window appears, click the **Choose File** button.




2. Update for Devices Running Firmware Version 15.04 or 15.5.x

- In the new window that appears, navigate to the location where the downloaded **padm_upgrade-15.5.3.1031.tar** file is stored. Select the file, then click **Open**. The window will close and return to Update window, showing the file name next to the Choose File button. Click the **Upload** button.



If using the PowerAlert Mass Updater utility (version 1.1.1 or later), click the **Browse** button and navigate to the location where the downloaded Firmware folder is stored. Select it, then click **OK**.



2. Update for Devices Running Firmware Version 15.04 or 15.5.x

- 3 A progress bar will indicate the start of the upload. When it is completed, click on the **Update** button. Please allow at least 10 minutes for the update to complete.



- 4 When the update is complete, clear the browser cache. Close, then reopen the browser and log in to the device's web interface.

Note: If the device had a dynamically assigned (DHCP) IP address, the IP address may be different after the upgrade.

2. Update for Devices Running Firmware Version 15.04 or 15.5.x

- 5 Go to the **About** page to confirm the update is successfully installed.

The screenshot displays the 'About' page of the Tripp-Lite PowerAlert Device Manager. The interface includes a sidebar with navigation options: Status, Control, Configuration, Logs, About, and Active Alarms (showing 0 lightning bolts, 0 exclamation marks, and 0 information icons). The main content area is titled 'About' and shows the following system information:

Item	
Operating System	Ubuntu 16.04.4 LTS Linux 4.4.31 flash: 3.5G ram: 247204kB processor: armv7l
Agent Type	Nmc5
MAC Address	00:06:67:40:1D:A4
Serial Number	2702AV016769700093
PowerAlert Driver Version	15.5.3 (Build 1031)
PowerAlert Console Version	15.5.3 (Build 1031)
PowerAlert Engine Version	15.5.3 (Build 1031)
Driver File Status	Normal
SNMP v3 Engine ID	8000035203000667401da4

Copyright (c) 2008-2018 by Tripp Lite. All Rights Reserved.

