

Owner's Manual

USB 2.0 to SATA / IDE Adapter

Model: U238-000-1

Package Includes	2
Features	2
Installation	3
Warranty and Product Registration	4

PROTECT YOUR INVESTMENT!

Register your product for quicker service
and ultimate peace of mind.

You could also win an ISOBARGULTRA
surge protector—a \$100 value!

www.triplite.com/warranty



1111 W. 35th Street, Chicago, IL 60609 USA • www.triplite.com/support

Copyright © 2016 Tripp Lite. All rights reserved.

Package Includes

- U238-000-1 USB 2.0 to SATA / IDE Adapter
- USB 2.0 Cable – 2.5 ft.
- 4-Pin Molex Power Cable
- External Power Supply (Input: 100-240V, 50/60Hz, 0.8A Output: 12V, 2A)
- Owner's Manual
- Backup Software CD

Features

- Connects a SATA and/or IDE drive to the USB port on your computer
- Supports simultaneous connection of SATA and IDE drives, allowing data transfer between them
- Allows easy configuration of hard drives
- Features 40-Pin and 44-Pin connectors for use with 2.5", 3.5" or 5.25" IDE drives
- Includes software for backing up and restoring your files; backup software is compatible with Windows® XP, Vista, 7, 8, 8.1 and 10

Installation

Notes:

- *Hard drives are sensitive to static electricity and must be handled properly to prevent data loss. Always handle your hard drive with caution: wear an anti-static strap when transporting it, or touch a grounded metal surface to discharge yourself of static electricity before picking up the drive.*
- *If your drive has not been formatted, you need to format it using your computer's Disk Management utility before you can copy and access files.*
- *Before unplugging the adapter, make sure to properly eject the drive from your computer to avoid any potential data loss.*

- 1.** Connect the U238-000-1 to your computer using the included USB 2.0 cable.
- 2.** Connect the external power supply to the U238-000-1 and plug it into an appropriate power source.
- 3.** Connect your SATA and/or IDE drive to the appropriate port on the U238-000-1. Use the included 4-Pin Molex cable to provide power to your IDE drive.
- 4.** Upon connecting a drive, your computer will recognize it, making it available for access.
- 5.** To install the included backup software, insert the CD packaged with the product. If your computer doesn't have a CD drive, you can download the software at www.tripplite.com/support. Navigate to and run the setup.exe file, following the prompts that appear to install it on your computer.

One Button File Backup

The One Button Backup function performs a backup according to the settings you enter in the J-Micron Backup utility. Simply connect your hard drive via the USB port on your computer, and press the backup button on your U238-000-1 adapter. The backup will take place according to the settings you have entered.

Warranty and Product Registration

1-Year Limited Warranty

TRIPP LITE warrants its products to be free from defects in materials and workmanship for a period of one (1) year from the date of initial purchase. TRIPP LITE's obligation under this warranty is limited to repairing or replacing (at its sole option) any such defective products. To obtain service under this warranty, you must obtain a Returned Material Authorization (RMA) number from TRIPP LITE or an authorized TRIPP LITE service center. Products must be returned to TRIPP LITE or an authorized TRIPP LITE service center with transportation charges prepaid and must be accompanied by a brief description of the problem encountered and proof of date and place of purchase. This warranty does not apply to equipment, which has been damaged by accident, negligence or misapplication or has been altered or modified in any way.

EXCEPT AS PROVIDED HEREIN, TRIPP LITE MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

EXCEPT AS PROVIDED ABOVE, IN NO EVENT WILL TRIPP LITE BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. Specifically, TRIPP LITE is not liable for any costs, such as lost profits or revenue, loss of equipment, loss of use of equipment, loss of software, loss of data, costs of substitutes, claims by third parties, or otherwise.

Warning

Use of this equipment in life support applications where failure of this equipment can reasonably be expected to cause the failure of the life support equipment or to significantly affect its safety or effectiveness is not recommended. Do not use this equipment in the presence of a flammable anesthetic mixture with air, oxygen or nitrous oxide.

PRODUCT REGISTRATION

Visit www.triplite.com/warranty today to register your new Tripp Lite product. You'll be automatically entered into a drawing for a chance to win a FREE Tripp Lite product!*

* No purchase necessary. Void where prohibited. Some restrictions apply. See website for details.

FCC Notice, Class B

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Note: *This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications to this equipment not expressly approved by Tripp Lite could void the user's authority to operate this equipment.

WEEE Compliance Information for Tripp Lite Customers and Recyclers (European Union)

Under the Waste Electrical and Electronic Equipment (WEEE) Directive and implementing regulations, when customers buy new electrical and electronic equipment from Tripp Lite they are entitled to:

-  Send old equipment for recycling on a one-for-one, like-for-like basis (this varies depending on the country)
-  Send the new equipment back for recycling when this ultimately becomes waste

Tripp Lite has a policy of continuous improvement. Specifications are subject to change without notice.



1111 W. 35th Street, Chicago, IL 60609 USA
www.triplite.com/support